www.farrierproducts.com • 1-800-468-2879










NEWS FOR FARRIERS

Be Prepared for Colder Weather with Traction Devices

Kerckhaert Snow Rim Pads

Kerckhaert Snow Rim pads come in both urethane (clear) and rubber (black). The urethane pads are longer-wearing for heavy winter use. Each pair comes in an individually wrapped package.



For those situations when you need only enough traction to prevent sliding or slipping on hard surfaces, Tungsten Carbide Pins, Drive-In Studs and Vector V-Trak nails are very simple to apply.

Simply drill with a bit and seat the tapered shaft of the stud into the hole. It's amazing how much confidence your horses will gain when on blacktop or concrete. The studs should also give good traction for trail riding in terrain with large rocky footing. 50 pieces per pack.









As with the Drive-In Studs, you seat the tapered shaft of the pin into the hole. Holes may be drilled in toe or heel of the shoe. Installation requires the use of a drill bit - included with every package of 100 pins.

Mark your Calendar to Participate in Upcoming Educational Events

INTERNATIONAL HOOF-CARE SUMMIT

JANUARY 23 - 26, 2018 CINCINNATI, OHIO americanfarriers.com/ihcs

47TH ANNUAL AFA CONVENTION

FEBRUARY 27 - MARCH 2, 2018 RENO, NV americanfarriers.org/convention/2018-convention-reno-nv/

For more farrier events near you, visit FPD's online calendar at farrierproducts.com/calendar.html.

JUST A REMINDER

Liberty Cu Copper Coated Race Nails with Cu (Copper) Shield Technology

In addition to all of the same great features of the regular Liberty nail, the Liberty Cu horseshoe nails include Copper (Cu) Shield Technology. This technology provides more



protection than traditional horseshoe nails. Hoof wall, white line and sole are stronger and healthier when Liberty Cu nails are used on a daily basis. The Copper(Cu) Shield Technology is unique to Kerckhaert and Liberty Cu horseshoe nails.



Winter Traction Tips

BY BOB SCHANTZ


This is an excerpt from FPD's Field Guide » www.farrierproducts.com/fieldguide/tools/tractiontips.html

Tinter can create traction problems for horses, and therefore for farriers charged with their care. Care should be used when deciding how much traction is needed. Excessive traction can create torque to the limbs, too little allows the horse to slip or fall. In addition to forged caulks, there are four primary traction devices that you can apply to horseshoes:

- Borium Head Nails
- Drive-in Studs and Pins
- Screw-in Caulks
- Borium or Drill Tek

Each type of traction device requires special skills and knowledge for proper application. In this except we'll discuss Drive-In Studs.

TECHNIQUES FOR APPLYING DRIVE-IN STUDS







- 2. Do not drive the stud to the bottom of the shoe. The shaft of the stud is tapered and will tighten as the hoof bears the weight of the animal. If you drive it to the bottom of the shoe the stud will loosen and dislodge. Leaving about 1/8" will help ensure the studs remain where you put them.
- 3. Do NOT use your good hammer to drive the studs into the shoe. Either keep an old hammer for this purpose or place a piece of flat steel on top of the stud and hammer on the steel.

Connect with FPDand Join the Conversation

Facebook

Like FPD's Facebook page to view, like, share and comment on industry news,photos, videos and events.

facebook.com/FarrierProductDistribution

YouTube

Subscribe to FPD's YouTube channel for educational farrier videos that offer real world application for farriers of all skill levels.

youtube.com/farrierproducts

Instagram

Follow @fpdinc to view, favorite, share and comment on industry photos and videos.

instagram.com/fpdinc

FPD Field Guide

A useful on-the-go guide to the best horseshoes, nails and tools for various disciplines with tips and videos on how best to use them.

farrierproducts.com/fieldguide

HoofWall™ Blog

FPD explores the world of the professional farrier as they travel through North America and offers practical educational material for farriers.

farrierproducts.com/blog









